

## **TIGHTENING METHOD**

### **BLT-MK-STUD-DUR-2.0L**

#### **Main stud kit.**

ISSUE DATE: August 2015

PAGE No: 1 of 1

If you are using our main stud kit with our SBD/Titan dry sump system, please ensure you read the dry sump fitting instructions before continuing.

---

## **METHOD**

**ARP lubricant must be used on all threads and underneath face of nut and washer.**

### **BEFORE CRADLE IS INSTALLED: -**

- 1. Ensure threads in block & on stud are completely clean**
- 2. Apply lubricant to stud threads & screw stud into block finger tight only.**

**Once crank and cradle is installed, fit nut & washer then: -**

**STAGE 1---25 LB/FT**

**STAGE 2---Back off ½ turn**

**STAGE 3---25 LB/FT**

**STAGE 4---60 LB/FT**

**STAGE 5---Back off ¼ turn**

**STAGE 6---60 LB/FT**

**DURATEC MAIN STUD**  
**TIGHTENING SEQUENCE**

<b>8</b>	<b>4</b>	<b>1</b>	<b>5</b>	<b>9</b>
<b>7</b>	<b>3</b>	<b>2</b>	<b>6</b>	<b>10</b>

**DURATEC MAIN STUD**  
**REMOVAL SEQUENCE**

<b>3</b>	<b>7</b>	<b>10</b>	<b>6</b>	<b>2</b>
<b>4</b>	<b>8</b>	<b>9</b>	<b>5</b>	<b>1</b>



SBD Motorsport Ltd,  
Unit 15, Red Lion Business Park, Red Lion Road, Surbiton, Surrey KT6 7QD.  
Tel:020 8391 0121.  
Email:sbdmotorsport@btconnect.com  
Web:www.sbdev.co.uk