

## **Carbon & Steel Exhaust Box Repackaging**

1. Mark tube & End caps (To ensure correct positioning on re assembly).
2. Remove end caps & discard packaging (if your box was originally packed with stainless steel mesh and wading, please discard both).
3. Roll packing material around perforated tube, placing tube at one end and rolling up to the other end.
4. Carefully slide entire roll into the centre of the steel or carbon tube and locate the perforated tube at the bottom.
5. Assemble end caps as required matching your own markings.
6. The brown parcel tape at the end of the material will burn off when engine is first run.



SBD Motorsport Ltd  
Unit 15, Red Lion Business Park, Red Lion Road, Surbiton, Surrey. KT6 7QD  
Tel:0208 391 0121  
Email:sbdmotorsport@btconnect.com  
Website:sbdev.co.uk