

MBE9A4i PIN LIST

Connector Types: J2 = Delphi 36 way

PIN No	9A4i General Function
1	N/A
2	Water Temp
3	Air Temp
4	5VA Ref
5	0VA
6	Power Ground
7	Power Ground
8	CANL
9	CANH
10	Permanent 12V Supply (Battery)
11	Crank Return
12	Crank Signal
13	Switched 12V Supply (Key)
14	N/A
15	Ignition D (4th to fire)
16	Programmable Low Side Output Pin
17	Programmable Low Side Output Pin
18	Ignition B (2nd to fire)
19	Programmable Input Pin
20	TPS
21	MAP
22	5VA Ref
23	0VA
24	0VA
25	Programmable Input Pin
26	N/A
27	Programmable Input Pin
28	Baro
29	N/A
30	Cam Signal
31	Cam Return
32	N/A
33	Programmable Low Side Output Pin

34	Programmable Low Side Output Pin
35	Ignition C (3rd to fire)
36	Ignition A (1st to fire)